

# Ergo Steel II + Base

**ERGO**<sup>®</sup>  
STEEL II + Base  
EDGE MAINTENANCE TOOL



**Ergo Steel II now available with Table Base  
in convenient single pack!**

**Restore a perfect, razor-sharp edge in seconds!**

## **Ergo Steel II**

- Perfect edge in seconds.
- Aligns both sides of the blade simultaneously.
- Straightens and prolongs the edge life of all knives.
- Can be hand-held or bench-mounted.
- Optional handle for hand-held operation can be attached for left or right handed use.
- Totally enclosed, sanitary spring mechanisms.
- Easy maintenance and cleaning.
- USDA and CE certified.

## **Ergo Steel II Table Base**

- Holds the Ergo Steel II firmly in place.
- No tools required. The Ergo Steel II “snaps” easily and securely into the Table Base.
- Simple tab-release to separate the Ergo Steel II from the Table Base.
- Holds tightly to virtually any smooth flat surface.
- Compact size allows positioning of the Ergo Steel II close to the work space for maximum comfort and efficiency.
- Lightweight for easy portability allows use where it is needed most.
- Easy maintenance and cleaning.

REV 07/19/2023

# HES-2+B: Ergo Steel II+Base

Requiring no training, the PRIMEdge Ergo Steel II is used to quickly straighten and restore a knife's cutting edge to razor-sharp performance. The Ergo Steel II Table Base holds firmly to virtually any smooth flat surface, and is the ideal portable, removable, secure solution for positioning your Ergo Steel II.

The Ergo Steel II consists of a pair of pivoting, hardened stainless steel tempered rods in a food-grade injection molded polypropylene frame. Under each pivoting rod, fully enclosed spring mechanisms provide the perfect amount of tension between the knife edge and stainless steel rods allowing both sides of the knife edge to be straightened simultaneously producing a perfect edge.

As a knife edge dulls, slide the blade through the unique spring-tensioned rods of the Ergo Steel II to straighten the knife edge in a matter of seconds.



First insert knife and push to bottom of Ergo Steel II then draw knife out.



Then insert knife again and push to middle of Ergo Steel II and draw knife out. Repeat.



**PRIME**Edge  
CUTTING EDGES & SHARPENING SOLUTIONS



To remove the Ergo Steel II from the Table Base, spread the locking tabs on the Table Base and lift the Ergo Steel II out.

